

# The Atari 1600/7800 Prosystem Sound Development Tool

Version 0.40 August 2, 1988

Programmer: Kenneth Soshon  
with Dave Stumpes  
Copyright 1988 Atari Corp.

## Introduction

The Atari 7800 Prosystem includes the Atari 1600 game system's chips on board, to enable it to play the huge number of existing 1600 games-- as a direct result of having access to the 1600 chip set, the 7800 has some of the abilities of the 1600 to free up processor time and save on chip costs-- thus the 7800 sounds are generated through the 1600 sound processor. The Atari 1600/7800 Prosystem Sound Development Tool enables the Atari ST owner to develop 1600/7800 sounds in the ST environment. The Sound Tool gives the user a graphic development environment for sound, with quick and easy storage and retrieval. To use a sound developed with the Sound Tool, the user can store the sound as data in the Atari HAMMC 1001 assembly format and play it with a simple vertical blank routine.

## Hardware Requirements for Sound Tool

The Sound Tool runs on any Atari ST system computer, with either a black and white or a color monitor. Place the color monitor in medium resolution before running the Sound Tool. If you wish to hear the sounds on your 7800 hardware, you must connect the developer's card to the 7800 and the ST's parallel printer port. The interface card to the 7800 is NOT mandatory; you can develop sounds without hearing them, or simply do some editing without connecting.

## 1600 Sound Hardware Specifc

The Atari 1600 sound chip contains two channels, each with three control registers: Frequency, Volume, and "Control." The Frequency (ARF0, a ARF1) ranges from 0-31, and divider a 1000Hz signal to result in a 1000Hz - 16KHz range. The Volume control (ARV0, a ARV1) has sixteen steps 0-15, which directly control loudness. The Control register (ARC0, a ARC1) has sixteen positions, which cause the output signal to be some mixture of pure tone and noise:

control value	sound type
0	sil
1	Rich, low tones
2-3	Noisy, rich, low tones
4-5	Pure tone in middle range
6-10	Noisy, low range
11	White noise
12-13	Pure tone, lower range
14	---
15	low noise

The Frequency combined with the Control value determines the final output frequency, and noise content.

## Sound Tool Installation

The Sound Tool consists of two Atari ST files: SOUNDY.PRG, and SOUNDY.PIC. The executable and the resource must be in the same directory in order to run the Sound Tool, but you don't have to be in the same directory. The only requirements are that the system be set up for a GEM environment, and that the

first entry is `MPV` as the path + name of `SOCKET`. For example, in the Mark Williams shell, you must type `TERM F:\BIN\SOCKET` (if you put the Sound Tool in your BIN directory).

#### The Sound Tool Environment

The Sound Tool contains three main screens around the menu system, the sound development area, and the sound history. The Sound Tool menu system provides disk access, sound playback, sound display, and minor editing functions. The sound development area gives the user direct access to the 1600/7000 sound registers through slider bars. The user can experiment with notes until finding just the right one before adding it into the song. The sound history area gives visual feedback about the current song and enables changes of the notes in the body of the song as the fly. Each notes duration and value can be manipulated in the sound history area, providing a flexible, fast approach to editing the sound.

#### The Sound Tool Menu System

All commands in the Sound Tool can be accessed through the menu system, but most frequently used commands can be accessed through the keyboard. Read on for a description of all the available menu options in Sound Tool.

##### File

Load Voice(s)

Retrieve a file that was stored by the Sound Tool with the "Save Voice(s)" option by using this option. A file selection will appear, select the file to load and press OK. Cancel aborts the operation. If the loaded file only contains one voice, it will generate an empty voice if possible, and then the left hand voice.

Save Voice(s)

Outputs a file in Sound Tool format. The resulting file can be used by using the "Load Voice(s)" option (see above). The Sound Tool writes the data on the current voices to the file specified by the user with the file selector. If one voice is empty, it will not be written to disk. By convention, Sound Tool only format files have the `.SND` extension.

Save as .S File

When you've developed a sound that you want to include in a 1600 or 7000 game, you can produce an assembler format file representing the sound data using this option. The frequency, volume, control, and duration values for both voices are written out in a `SHMM` format file. Each "tick" is represented by a single byte of data. A simple vertical blinking interrupt routine can step through each array of data, delaying on the duration of each note.

##### Playback

Play Voice #1 (F1) and Play Voice #2 (F2)

Selecting "Play Voice #1 or #2" or hitting F(1 or 2) starts up the sound daemon which plays the voice through the 7000 system. Each "tick" corresponds to 1/60th of a second duration time. If a 7000 system is not connected, then these options are disabled. Note: No other options are available while the sound is being played back.

Play Both (F3)

Select "Play Both" or hit F3 to hear both voices played simultaneously.

##### Hardware

Top of Voice #1 and Top of Voice #2

Shifts the display so that the top of the voice is just below the active bar (middle of the sound history). In this position, you can add notes under the top of the sound.

Bottom of Voice #1 and Bottom of Voice #2

Moves the display so that the last note of the sound is inside of the active bar, and then notes can be added to the end of the sound.

Block

Copy Voice 1 -> 2 and Copy Voice 2 -> 1

Essentially clones the destination voice and places the source voice in the destination channel. Some developers like to make both voices identical, or just slightly different in frequency, and thus function simplifies development. \*Note: This function is irreversible.

Clear Voice #1 and Clear Voice #2

completely erases the given voice. \*Note: Once a voice is cleared, it cannot be restored.

Shift

Add to Voice #1 (Ctrl) and Add to Voice #2 (Ctrl)

Takes the note "inside" the sound channel bar at the bottom of the screen and adds it into the current sound, at the "active bar" location. The sound bar remains unchanged.

Delete from Voice #1 (Ctrl) and Delete from Voice #2 (Ctrl)

Removes the note inside the active bar from the appropriate voice. \*Note: Once a note is deleted, it is unrecoverable.

#### The Sound Development Area

The two sets of three slider bars at the bottom of the screen comprise the Sound Studio Sound Development Area. Each set of three sliders control a single voice's characteristics — Frequency, Volume, and Control. Manipulation of the sliders with the mouse sends the information directly to the TAGE via the Development Card (if connected). To change the value of a slider, just click the left mouse button while positioned in the slider area and the little thing in the slider bar will snap to the mouse position. Each slider's hexadecimal value is shown below the left edge of the slider. If you hold down the left button and drag the mouse, the sound will follow the position of the mouse. You can add notes while you hold the mouse button with the F5 and F10 keys, so you can develop a sound interactively while you hear it. Any note added will appear inside the "Active bar" for that voice.

#### The Sound History Area

The six vertical windows comprise the Sound History Area, each set of three displaying frequency, volume, and control values directly above and in line with the Sound Development Area values. Sounds that are added appear at the location of the active bar in the center of each window, the active bar back end in the history represents one "tick" of time, or 1/60th of a second initially, a note is one tick long, but some duration can be manipulated on the fly. Duration is represented vertically, so that each note's vertical length corresponds directly to its duration in "ticks." You can scroll the display of the history area by clicking on the arrows to the upper right of each set of three windows. The up arrow moves the view up while the down arrow shows more of the sound below the current view. Menu options "Top of Voice" and "Bottom of Voice" further position the view.

Refer: Manipulating...

Each note in a sound can be positioned on the fly while displayed in the History window. Click the left button in the window to reposition a note. If you click at a new position in the Frequency window, the entire note will jump to the new position. Creating a waveform is as easy as clicking and holding the left button, and then dragging down the voice — this will reposition each note you touch to your current position. Click and hold the right button to change the duration. After you click and hold the right button, the cursor will change into the horizontal representation of the duration of that note in "ticks." Roll down with the mouse to increase the length, and push up to decrease. The mouse / number will change to note movement. Let go of the right button to view the changed note.

#### POSITIONS & COMMENTS

We would appreciate your commentary on the 1600/7450 Prosystem Sound Tool, especially suggestions for improvements, and bugs. Please write your comments down and send them to:

ATARI CORPORATION  
AT&T, 1400 STANIS  
1188 SOMMERSET AVENUE  
SOMERVILLE, CA 94063

or call Ben Becker (before August 18, 1988) at (408)745-5010  
table area options in Sound Tool.